



CLEANING AND MAINTENANCE OF ULTRATEX 2200 & ANVILTEX 2100

SPOT CLEANING: Start by wetting the surface with clean water, then spray with soapy water and scrub with a stiff scrub brush, a non-metallic abrasive pad or a sponge/pad combination. Make your soapy water spray with a mild dish washing detergent liquid diluted 80% (1 to 5). If after repeated washing attempts with the soapy water scrub method does not remove the marks, spray the damp area with a good, non-colored, general household spray cleaner and scrub again. Please note: always rinse the cleaning products off the wall with plenty of clean water and then blot dry with a clean towel.

MORE DIFFICULT SPOT CLEANING: Always start the cleaning process using the mildest method above first. If the spot remains after using the mild method above, proceed on to scrubbing with an abrasive powder, so long as it is rinsed from the surface thoroughly and blotted dry. If a spot persists, first dampening the area with clean water and then mist spray on denatured alcohol or paint thinner on the dampened surface. Scrub with a stiff scrub brush and rinse thoroughly and blot dry with a clean towel. Please note: do not use bleach or acid based cleaners for they will soften the coating, full hardness will return to the finish when it dries, but discoloration will occur.

ANNUAL OR LARGE AREA CLEANING: A hand pump garden type sprayer is a handy tool for cleaning large areas. Simply, mix a solution of mild dish washing detergent liquid and water diluted 80 % (1 to 5), apply to walls with the sprayer and lightly scrub the surface with a brush or a clean broom. Using another hand pump garden type sprayer filled with clean water, flood rinse the surface thoroughly and blot dry with clean towels. Please note: thorough rinsing is very important, to remove soap residue from the surface.

MILDEW CLEANING: If organic substances have soiled the surface (food, soft drinks, hand oils or other substances which provide nutrition for organisms or insulates the organisms from contacting the UltraTex 2200 or AnvilTex 2100 surface) simply clean the surface as described in spot cleaning and the mildew growth will stop.