

CURVED BALCONY FRAMING SPECIFICATIONS

Finished Dimensions





Rough Framing Dimensions



- Refer to the Framing Specification chart to determine the dimensions of the desired balcony.
- Balcony will arrive with a template for rough framing to be cut to.
- Balcony's are designed to cover 3 1/2" of rough framing, therefore a smooth cut is not necessary.

| Curved Balcony Framing Specifications and Finished Dimensions (All Dimensions in Inches) | | | | | | | |
|--|---|-------|--------------------------------|-------------------------------|---|--------------------------------------|-------|
| | | | Finished Width | | | Dimensions of Rough-In Framing | |
| Balcony Model # | Recommended Grand Opening Model # * | 3 | Outside of Landing Tread | Inside of Landing Tread | Center of Rail to Center of Rail | Width | Depth |
| 55 | M32 | 2' 8" | 55 | 42 1/2 | 46 1/2 | 48 | 19 |
| 61 | M38 | 3' 0" | 61 | 48 1/2 | 52 1/2 | 54 | 19 |
| 73 | M50 | 4' 0" | 73 | 60 1/2 | 64 1/2 | 66 | 19 |
| 85 | M62 | 5' 0" | 85 | 72 1/2 | 76 1/2 | 78 | 19 |
| 97 | M74 | 6' 0" | 97 | 84 1/2 | 88 1/2 | 90 | 25 |
| 109 | M86 | 7' 0" | 109 | 96 1/2 | 100 1/2 | 102 | 25 |
| 121 | M96 | 8' 0" | 121 | 108 1/2 | 112 1/2 | 114 | 25 |

^{*} Smaller sizes can always be used. Larger door/openings may be used depending on width of casing. Refer to **Finished Inside of Landing Tread** Dimensions to determine if a larger size can be used.